

HNx High Peak Power PicoSpark[™] Series



KEY FEATURES

- 1064nm and 532nm
- Ultra-short pulses down to 500ps
- High Rep Rate up to 100kHz
- AOM option @532nm
- Peak power over 200kW
- Excellent beam quality TEM00, M²<1.2
- Efficient, air-cooled
- Sealed package, long life

The PicoSpark[™] series combine multi-watt output level with high repetition rate and exceptional pulse characteristics to provide the best price/quality ratio for micromachining application. Passively Q-Switched (PQS) microchip laser technology and fiber amplification are brought together, delivering pulses with hundreds of kilowatt peak power and hundreds of gigawatt per square centimeter power density in a sealed and air-cooled compact package.

This Master Oscillator Fiber Amplifier (MOFA) architecture notably offers a full control over the pulse energy (or peak power) while leaving unchanged the pulse width and pulse shape. An Acousto-Optic Modulator (AOM) option is also available to offer a rapid control of the repetition rate without distortion of the pulse and high energy stability from the first pulse on.

APPLICATIONS

- Micromachining
 Selective ablation of µm to nm scale layers
 - Edge isolation
 - Cutting from PCB to PCD with no heat effect
- Instrumentation
 - Laser Induced Breakdown Spectroscopy
 - Raman spectroscopy
 - Supercontinuum generation
 - Ranging
 - Differential absorption LIDAR
- Biophotonics
 - Dense tissue ablation
 - Micro-surgery

All information contained herein is believed to be accurate and is subject to change without notice. Teem Photonics may not be held liable for its use. Teem Photonics, its subsidiaries and affiliates, reserve the right to modify or withdraw, at any time and without any notice, specifications, product design, product component. Some options may not be available for all products. Please contact Teem Photonics for details. August 18



TECHNICAL SPECIFICATIONS

	HNP-70F-100 ⁽⁴⁾	HNG-70F-100
Wavelength	1064nm	532nm
Repetition Rate	>70kHz ⁽⁵⁾	>70kHz ⁽⁵⁾
Constant Pulse width range (FWHM)	<0.65ns	<0.65ns
Output power	>5.8W	>3.5W
Output energy	>72µJ ⁽⁶⁾	>45µJ ⁽⁷⁾
Peak Power	>110kW ⁽⁸⁾	>70kW ⁽⁹⁾
Short term(10min) power stability ⁽¹⁾	<±3%	<±3%
Long term (6 hrs) power stability ⁽¹⁾	<±5%	<±5%
Beam profile	Gaussian TEM00	Gaussian TEM00
Beam diameter at output	2.8mm±0.5mm	0.65mm±0.2mm
Full angle divergence @1/e ² Horizontal Vertical	0,5±0.2 mrad 0,5±0.2 mrad	3±1 mrad 3±1 mrad
M²(2)	<1.2	<1.2
Beam ellipticity ⁽³⁾	<1.20	<1.22
Polarization	Linear PER>20dB	Linear PER>20dB
Energy control function	RS232, Analog 0-5V	RS232, Analog 0-5V
Gating function	TTL 0-5V	TTL 0-5V
Synchronisation output included	TTL compatible output signal for synchronization/monitoring	TTL compatible output signal for synchronization/monitoring
Option*	-	А

NOTES

(1) For temperature variation $< \pm 3^{\circ}$ C and $< 3^{\circ}$ C/hour, stability is measured with calorimeter - detector band [DC, 2Hz] (2) Mean average value M = $\sqrt{(XY)}$, X and Y being respectively the major and minor axis of the ellipse (3) Beam ellipticity is calculated as the ratio of the main axis far field divergence

(4) Contact factory for availability. Performances are given without optical isolator.

(5) The repetition rate can be factory-set to any fixed higher (up to 100 kHz) or lower (down to 30 kHz) value. The energy per pulse would decrease / increase accordingly.

(6) The energy per pulse of the HNP-70F-100 can be factory-set up to 100μ J, the repetition rate would have to be decreased

(7) The energy per pulse of the HNG-70F-100 can be factory-set up to 60µJ, the repetition rate would have to be decreased

(8) The peak power depends on the energy per pulse customization and the laser pulse width (up to 200kW for the HNP-70F-100)

(9) The peak power depends on the energy per pulse customization and the laser pulse width (up to 100kW for the HNG-70F-100)

* Described on page 3

www.teemphotonics.com

HNx series I 2/5



COMPLEMENTARY INFORMATION & OPTIONS

Environment Parameters		
Operating Temperature Range	15-30°C	
Maximum Power Consumption	<600W	
Storage Temperature	0-50°C	
Shock of 11ms according to IEC 68-2-27, non operating	25g	
Vibration 5Hz to 500Hz sinusoïdal according to IEC 68-2-6	2g	

Certification	
Laser classification according to IEC 60825-1:2007	4
CDRH compliance	Yes
ROHs	Yes

Package		
Laser Head dimensions, LxWxH	429x250x120mm	
Laser Head weight	9kgs	
Cable length between head and controller	2m	
Controller dimensions, LxWxH	483x390x88mm	
Controller weight	10kgs	


Option	
Acousto-Optic Modulator (A)	For HNG series only

All information contained herein is believed to be accurate and is subject to change without notice. Teem Photonics may not be held liable for its use. Teem Photonics, its subsidiaries and affiliates, reserve the right to modify or withdraw, at any time and without any notice, specifications, product design, product component. Some options may not be available for all products. Please contact Teem Photonics for details. August 18



FOR YOUR APPLICATION, FIND YOUR PULSED LASER SOLUTION

CDRH LASER HEAD MECHANICAL DRAWINGS




www.teemphotonics.com

HNx series I 4/5



FOR YOUR APPLICATION, FIND YOUR PULSED LASER SOLUTION

CDRH CONTROLLER MECHANICAL DRAWINGS



All information contained herein is believed to be accurate and is subject to change without notice. Teem Photonics may not be held liable for its use. Teem Photonics, its subsidiaries and affiliates, reserve the right to modify or withdraw, at any time and without any notice, specifications, product design, product component. Some options may not be available for all products. Please contact Teem Photonics for details. August 18

www.teemphotonics.com

HNx series I 5/5